

# GUIDA

## ALLA CONFIGURAZIONE DELL'ACCOUNT VoIP DI PARLA.IT

ROUTER : TELSEY  
 Modello : CPVA4V2  
 Firmware : 3.4.9V-sip.A2pB020d.d17m  
 Bootloader (CFE): 1.0.37-3.7

Accedere al menu di configurazione del router. Cliccare su:

**VOICE -> SIP**

per visualizzare la schermata **Voice -- SIP Configuration**.

Compilare i vari campi e selezionare le opzioni affinché la configurazione corrisponda **esattamente** alla schermata di esempio seguente; inoltre si dovranno sostituire le diciture **“numero VoIP”** con il dato di Login presente nella e-mail di attivazione e inserire la Password fornita con la stessa e-mail nel campo **Password Line 1**.

Cliccare sul bottone **Start Sip Client** per completare la configurazione.

**telsey**  
telecommunications  
to enable the future

### ADSL Home Access Gateway

Voice -- SIP configuration

Interface name:

SIP domain name:

Use SIP Proxy.  
 SIP Proxy IP Address:  Alternate SIP Proxy:   
 SIP Proxy port:  Alternate SIP Proxy port:

Use SIP Outbound Proxy.

Use SIP Registrar.  
 SIP Registrar IP Address:  Alternate SIP Registrar:   
 SIP Registrar port:  Alternate SIP Registrar port:   
 SIP Time to Live (sec):  Retries:   
 Timeout (sec):

Remote server for SIP log messages.

Transport protocol type:

SDP export type:

OutOfBand DTMF:

Supplementary services codes:

Supplementary services mask:

MWI service:

Sip messages TOS:

**Lines configuration**

Lines.  
 Line 1 phone:  Line 1 dialplan:   
 Line 2 phone:  Line 2 dialplan:

Digest authentication.  
 Username Line 1:  Password Line 1:   
 Username Line 2:  Password Line 2:

©2005 Telsey Telecommunications. All rights reserved.